

Berenda

- Remove exiting soil and concrete
- Pour concrete back at 3.5 inches (approximately 1461 sq/ft).
- Control joints to match exiting or every 12 feet.
- Dowel into existing concrete every 2 feet with #4 rebar
- Rebar is to penetrate 8 inches into existing concrete and protrude 18 inches.

